

---

*Firstly assemble the by blind placing all components face down on a clean surface. Guide the two side channels into the exposed arms of the top frame corner joints, until they are secure and tighten the screws attached. Repeat the process with the bottom section of frame to complete the blind.*

---



---

*To line up the brackets, place a credit/store card vertically against the glass at the top of the window. Where the bottom of the card sits, this is the installation point for the first bracket.*

*Install all of the brackets provided, installing any intermediate brackets accordingly.*

---

---

*Once the brackets are in place, simply line up the framework with the brackets and click it into place. For Perfect Fit venetian blinds, attached the tilt wand and the blind is now ready to operate.*

---

